SINGER

SINCE
Special Edition
1851

Feature	Benefit
LCD Screen with Stitch Selection Dial	Provides clear and easy viewing of stitch settings including the number and image of the selected stitch, stitch length settings and stitch width settings.
Block Alphabets and Numerals Included	Personalize projects by adding a monogram, name, phrase or date with the built-in block style alphabets and numeric stitches.
SwiftSmart™ Threading System with Automatic Needle Threader	Simply guide the thread directly from the spool to the needle area through a single groove and thread the needle by simply pressing the lever for effortless threading!
Programmable Needle Up / Down	The needle can be programmed to stop in the highest *up* position, making it easier to remove fabric from the machine. The needle can also be programmed to stop in the *down* position which is ideal for pivoting, appliquéing and quilting.
Stitch Memory with Editing	Save and edit select stitch combinations to create personalized designs!
Automatic Twin Needle Mode	Select stitches automatically adjust for twin needle sewing with just the touch of a button.
Automatic Stitch Length & Width	Optimal settings for stitch length and width are automatically set, but can be overridden for more personalized sewing.
Pattern Elongation	Press the Elongation button and eight stitches are made 2 to 3 times longer.
Presser Foot Sensor	Ensures the presser foot is in the proper position for an easy start. The machine will not begin to sew if the presser foot is raised, reducing the chance of thread bunching.

SINGER

SINCE
Special Edition
1851

Feature	Benefit
Drop & Sew™ Bobbin System	With this special top drop-in bobbin system, there's no longer any need to raise the bobbin thread before sewing. Just drop and sew!
3 StayBright™ LED Lights	Three lamps illuminate the sewing surface for optimal viewing. The long-lasting bulbs (100,000 hours) stay cool regardless of how long the machine operates.
Extra-Large Sewing Space	The arm of the machine measures 14.7" providing a more spacious work area—an essential for quilting, home décor sewing or when working with other large projects.
Start/Stop Button and Speed Control	Unplug the foot control, press the Start button and the machine sews. You are still in complete control over the speed - just slide the Speed Control lever to the desired speed.
231 Built-In Stitches with 1,000+ Stitch Functions	Basic, stretch, decorative, buttonholes, alphanumeric
6 Fully Automatic 1-Step Buttonholes	Buttonhole sewing is a simple one-step process, providing reliable results every time. Each side is sewn in the same direction creating balanced buttonholes.
Endless Buttonhole	Create buttonholes with endlessly long sides for large buttons or ribbons.
Exclusive Buttonhole Underplate	The buttonhole underplate ensures perfect buttonholes on multiple fabric layers. It makes sewing buttonholes possible in places that conventional buttonhole devices cannot easily reach.
Direct Selection Buttons	The three most popular stitches are accessible at the touch of your fingertips. The other stitches are simply a dial away.
7mm Stitch Width	Many satin and decorative stitches can be set for a maximum width of 7mm.

SINGER

SINCE 1851 Special Edition

Feature	Benefit
Heavy-Duty Metal Frame	The internal rigid support holds all the mechanisms in perfect alignment for skip-free sewing and overall durability.
Free Arm	Provides access to cuffs, collars, pant hems and other difficult-to-reach areas.
One Cycle Stitch Button	On select stitches, the One Cycle Stitch button sews a single unit of the stitch, allowing for complete creativity. When you press the button when sewing a stitch sequence, the machine will stop at the end of the cycle being sewn.
Tacking Stitch Button	Tie-off any stitch with just a push of the Tacking Stitch button. Three tiny tacking stitches reinforce patterns and stitches to prevent unraveling.
Center Zigzag Taper	When tapering with the zigzag stitch, the stitch tapers to the center not the left or right, providing a more attractive look when tapering into or out from a point.
Automatic Tension	This system ensures stable stitch quality regardless of the type of fabric.
Drop Feed	A conveniently located lever lowers the feed dogs for free-motion embroidery, monograms and button sewing.
7-Segment Feeding System	This is a specially designed feed dog that ensures that the fabric is picked up and supported from the front of the presser foot to the back. This provides for accurate feeding of the fabric.
Box Feed	This is a function that moves the feed dogs in a box motion, rather than the historic arc motion. Box motion assures perfect feeding throughout the entire feed process, as the feed dogs are always in perfect and equal contact with the fabric and presser foot.

SINGER

SINCE
Special Edition
1851

Feature	Benefit
Automatic Presser Foot Pressure Control	The amount of pressure exerted on the fabric by the presser foot against the feed dogs is adjusted automatically. Sew from the lightest weight tricots to the heaviest denim, without making presser foot pressure adjustments.
Automatic Reverse	Push the conveniently located automatic reverse button to sew in reverse and reinforce the stitch.
Sewing Speed	With a maximum sewing speed of 750 stitches-per-minute, projects can be sewn quickly.
Thread Cutter	Located on the machine for precise thread cutting, eliminating the extra step of cutting thread with scissors.
13 Needle Positions	Needle position can be changed for individual projects like inserting zippers, cording and topstitching.
Accessory Storage	The accessories are conveniently stored in the removable storage compartment providing easy access.
Snap-On Presser Feet	Easily change snap-on presser feet without use of a screwdriver.
Extra-High Presser Foot Lifter	Offers more clearance, which is needed when placing multiple layers or bulky fabric under the presser foot.
Horizontal Threading	Quality stitches begin with proper thread delivery. Placing the thread spool in the horizontal position allows for the thread to feed more evenly, reducing poor stitch formation and thread breakage.
DC Motor	Provides instant start up and stop with no coasting, for accurate and precise stitch placement.

Feature	Benefit
Included Accessories	All-Purpose Foot Zipper Foot Buttonhole Foot with Underplate Blind Hem Foot Satin Stitch Foot Pack of Needles Bobbins (Class 15J) Thread Spool Caps Auxiliary Spool Pin Spool Pin Felt Needle Plate Screwdriver Seam Ripper / Lint Brush Soft-Sided Dust Cover Instruction Manual with Stitch Guide Inside Quick Start Guide Foot Control Power Cord
Value Added Accessories	Beading Foot Braiding Foot Chenille Stitching Foot Cording Foot Darning / Freehand Embroidery Foot Edge Joining Foot Fancy Trim Foot Fringe Foot Invisible Zipper Foot Open Toe Foot Roller Foot Wing (Hemstitch) Needle Presser Foot Shank Value Added Instructions
Warranty	Limited 25-year warranty including 5-year electronic components and 1-year adjustments
Women's Choice	SINGER has earned the 2013 & 2014 Women's Choice Award™ for America's Best Home Sewing Machine. This award designation is based on a national survey among 5,000 women who were asked to select the brands they would most highly recommend to others.

SINGER, the Cameo "S" Design, SWIFTSMART, STAYBRIGHT and DROP & SEW are exclusive trademarks of The Singer Company Limited S.à r.l or its Affiliates.
©2014 The Singer Company Limited S.à r.l. or its Affiliates. All rights reserved.